



REALM1000 ADMINISTRATION

CONTENTS OF THIS DOCUMENT.

	<i>Page</i>
<u>REALM1000 with a domain</u>	2-3
Access Administration functions when using your own domain name.	
<u>REALM1000 without a domain</u>	4
Access Administration functions when not using a domain name.	
<u>Contact Information</u>	5
Contacting Realm networks.	



REALM1000 WITH A DOMAIN

ACCESSING REALM1000 ADMINISTRATION FEATURES WHEN USING A DOMAIN NAME.

Now that REALM1000 has been configured and rebooted, you have access to the **Administration** and **Members** interface.

The Administration interface can be accessed by connecting to the URL address https://admin.yourdomain** or <https://192.168.0.1>

An Administration account has been pre-installed for your convenience. We recommend you create a more personalized Administration account and change the password of the pre-installed account as soon as you first connect.

Username: **realmadmin**
Password: **password**

An FTP Administration account has been pre-installed for your convenience. We recommend change the password of the pre-installed account as soon as you first connect.

Username: **ftpadmin**
Password: **password**

**** *yourdomain* represents the Domain Name you have registered (i.e. realmnetworks.com)**

A Website Administration account has been pre-installed for your convenience. We recommend change the password of the pre-installed account as soon as you first connect. If you would like to upload your website please connect as the Website Administrator to the ftp site using an ftp client **ftp.yourdomain****.

username: **wwwadmin**
password: **password**



The Members section can be accessed by all accounts at the URL
http://members.yourdomain**

Username: **provided by Administrator**
Password: **provided by Administrator**

Your REALM1000 system has pre-configured the following Servers for you.

- https://admin.yourdomain** providing access to the Administration.
- http://members.yourdomain** providing access to the members section.
- http://www.yourdomain** providing access to your website.
- ftp.yourdomain** providing access to your ftp site.
- mail.yourdomain** providing access to your pop3 & smtp mail server.

**** yourdomain** represents the Domain Name you have registered
(i.e. realmnetworks.com)



REALM1000 WITHOUT A DOMAIN

IF YOU DONOT PROVIDE A REGISTERED DOMAIN NAME YOU WILL NOT BE ABLE TO ACCESS ALL THE FEATURES OF THE REALM1000 INTERFACE.

Now that REALM1000 has been configured and rebooted, you have access to the **Administration** interface.

Connecting to the URL address <https://192.168.0.1> can access the Administration interface

An Administration account has been pre-installed for your convenience. We recommend you create a more personalized Administration account and change the password of the pre-installed account as soon as you first connect.

Username: **lanceadmin**
Password: **password**

An FTP Administration account has been pre-installed for your convenience. We recommend change the password of the pre-installed account as soon as you first connect. You can use the FTP service of REALM1000 by connecting to the IP address provided by your ISP (i.e. 204.92.71.2)

Username: **ftpadmin**
Password: **password**



CONTACT INFORMATION

HOW TO GET IN CONTACT WITH REALM NETWORKS.

Address:

Realm Networks
1155 Lola St. Suite #8
Ottawa, Ontario, K1K 4C1
Canada

Telephone:

Tel: (613) 744-3401
Fax: (613) 744-2602

Online:

Web site: <http://www.realmnetworks.com/>

Email:

Sales: sales@realmnetworks.com
Support: support@realmnetworks.com
General Inquiries: info@realmnetworks.com
Site Inquiries: webmaster@realmnetworks.com